

**Supplement to**  
**MVME197LE**  
**Single Board Computer**  
**Installation Guide**  
**(MVME197LEIG/D1)**

The attached pages are replacements and/or additions to the installation guide. They correct a minor change.

Please replace the pages according to the following table and place this page behind the title page of the installation guide as a record of this change:

<b>Replace Old</b>	<b>With New</b>
A-3/A-4	A-3/A-4

- A vertical bar ( | ) in the margin of a replacement page indicates a text change or addition.
- The supplement number is shown at the bottom of each replacement page.

## **Notice**

While reasonable efforts have been made to assure the accuracy of this document, Motorola, Inc. assumes no liability resulting from any omissions in this document, or from the use of the information obtained therein. Motorola reserves the right to revise this document and to make changes from time to time in the content hereof without obligation of Motorola to notify any person of such revision or changes.

No part of this material may be reproduced or copied in any tangible medium, or stored in a retrieval system, or transmitted in any form, or by any means, radio, electronic, mechanical, photocopying, recording or facsimile, or otherwise, without the prior written permission of Motorola, Inc.

## **Restricted Rights Legend**

If the documentation contained herein is supplied, directly or indirectly, to the U.S. Government, the following notice shall apply unless otherwise agreed to in writing by Motorola, Inc.

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Motorola, Inc.  
Computer Group  
2900 South Diablo Way  
Tempe, Arizona 85282-9602

**Table A-1. ENV Command Parameters**

<b>ENV Parameter and Options</b>	<b>Default</b>	<b>Meaning of Default</b>
Bug or System Environment [B/S]	S	System is the standard mode of operation.
Field Service Menu Enable [Y/N]	Y	Display the field service menu.
Remote Start Method Switch [G/M/B/N]	B	Use both the Global Control and Status Register (GCSR) in the VMEchip2, and the Multiprocessor Control Register (MPCR) in the shared RAM methods to pass and start execution of cross-loaded program.
Probe System for Supported Disk/Tape Controllers [Y/N]	Y	Accesses will be made to the VMEbus to determine the presence of supported controllers.
Negate VMEbus SYSFAIL* Always [Y/N]	N	Negate VMEbus SYSFAIL after the successful completion or entrance into the bug command monitor.
Local SCSI Bus Reset on Debugger Setup [Y/N]	Y	The local SCSI bus is reset on the debugger setup.
Local SCSI Bus Negotiations Type [A/S/N]	A	Use Asynchronous negotiations on the local SCSI bus.
Ignore CFGA Block on a Hard Disk Boot [Y/N]	Y	Enable the ignorance of the Configuration Area (CFGA) Block (hard disk only).
Auto Boot Enable [Y/N]	N	The Auto Boot function is disabled.

Table A-1. ENV Command Parameters (Continued)

ENV Parameter and Options	Default	Meaning of Default
Auto Boot at power-up only [Y/N]	Y	Auto Boot is attempted at power-up reset only.
Auto Boot Controller LUN	00	LUN of a disk/tape controller module currently supported by the Bug. The default is \$0.
Auto Boot Device LUN	00	LUN of a disk/tape device currently supported by the Bug. The default is \$0.
Auto Boot Abort Delay	15	This is the time in seconds that the Auto Boot sequence will delay before starting the boot. The purpose of the delay is to allow the user the option of stopping the boot by use of the Break key. The time value is from 0 through 255 seconds.
Auto Boot Default String [NULL for an empty string]	<none>	The user may specify a string (filename) which is passed on to the code being booted. The maximum length of the string is 16 characters. The default is the null string.
ROM Boot Enable [Y/N]	N	The ROMboot function is disabled.
ROM Boot at power-up only [Y/N]	Y	ROMboot is attempted at power-up only.
ROM Boot Enable Search of VMEbus [Y/N]	N	VMEbus address space will not be accessed by ROMboot.